


Transfer Key

Product ID: TK



The Transfer Key is used to transfer information between the Acsys Lock and the Acsys Management Software System.

The primary role of the Transfer Key is to initialize/delete locks.

The other usage is to download locks' access logs and transfer them to the database. Finally, the Transfer Key is used to blacklist lost keys used on the locks.

GENERAL	
Dimensions	40 x 72 x 17 mm
Material	BLADE SUS 316L / TOP COVER PC+25% GF / LED LENS / SWIVEL SUS 304
ENVIRONMENT	
Temperature	-20 °C to 55 °C (Storage & Operation)
Relative Humidity (RH)	5 to 95% (Without Condensation)
ELECTRONICS	
Battery Type	2 x LR1
Battery Life	1 year
Encryption	AES 128-bit
Visual Indicator	LED: 1 x Tri-color (Green, Red, Orange)
COMPATIBILITY	
Locks	All Acsys lock types
CERTIFICATION	
	CE
WARRANTY	
Warranty	1 year ⁽¹⁾

¹ Batteries included in this product, are supplementary and are not part of the product warranty.